

Kramer Electronics, Ltd.



VP-426 Firmware Upgrade

Procedure

1. To perform the upgrade, the firmware file must be named *VP-426.bin* with no additional characters or numbers. If necessary rename the file.
2. Save the *VP-426.bin* file to a memory stick (upgrading from a PC is not available).
3. Disconnect power from the VP-426.
4. Plug the memory stick into the USB connector on the VP-426.
5. Press and hold the Menu button while reconnecting power to the VP-426.
6. When three LEDs light at the same time, release the MENU button (meaning the device is in the FW upgrading mode).
7. When the upgrade is complete, the LED goes from solid on to flashing.
8. Disconnect and reconnect the power cable.
9. Check that the Info screen shows the latest FW version.